

# USB 2.0 TO RFID-PROXIMITY

## USER GUIDE

### MSSSED USB-RFID proximity

**NEW**



USB 2.0 TO RFID-PROXIMITY

#### Product Features

- USB Specification Rev. 2.0 compliant
- External or internal antenna
- Anti-collision function
- Multi-tag reader ISO-14443-A ISO 15693 (30mm distance from reader)
- Transmission Speeds 19200 Baud 8bit nparity 1Bit stop
- Scan mode preset , ASCII notation
- Conditions of operation 0- 70 °C UR 25-85 %
- Power +5V (USB line) 250mA

#### System Requirements

- IBM PC 486DX4-100 Mhz CPU or higher or compatible system
- Available USB port
- CD-ROM drive
- Windows 2000,XP,Vista

#### Driver Installation XP

1. During installation, please don't link USB-rs485 with your computer
2. Double click 'setup.exe' then it will start install





### 3. Click Next



### 4. Click Continue Anyway



### 5. Click Finish

## 6. Restart your computer


## 7. Devices USB-rs485 connection



### 1. Click Next



### 2. Click Next






### 3. Click Continue Anyway



### 4. Click Finish

- Tag UID Unique identifier



- MFR code ( ISO15693 )

02H - ST MICROELECTRONICS  
04H - PHILIPS SEMICONDUCTOR  
05H - INFEON  
07H - TEXAS INSTRUMENTS  
16H - EM MICROELECTRONICS

- The UID is factory programmed and cannot be changed

- Scan-Mode

In this mode the reader automatically trasmit UID  
to host computer .  
ASCII notation

